



Position	Spare parts	Part number
1	Inverter board	033093040000
1.1	Compressor board	033093040100
1.2	Capacitor plate	033093040200
1.3	Current detector	033093040300
1.4	Fan motor board	033093040400
1.5	Three phase rectifier bridge	033093040500
2	PC board (Heat&Cool)	033090470300A40
3	Touch controller with built-in wifi	034092180001
4	Contactora 1	040010030000
5	Reactor	041301140000
6	Power filter plate	033090640000
7	Electronic expansion valve	006120140000
8	4-way valve	006110200000
9	Water flow switch	040060600000
10	Fan motor	032051610000
11	Fuse	040070050000
12	Full set of sensors	Z35043000500
13	Compressor	031062980000
14	Titanium heat exchanger (Heat&Cool)	001031190037 001031190035
15	Evaporator	Z01011890000 /
16	High pressure protection switch	040050650000
17	low pressure protection switch	040050150000
18	High&low Pressure valve	006080500000
19	Water union	003990150000
20	Fan	007010190000
21	Compressor insulation cap	004041640000
22	Top cover	002021610915
23	Rear pole	0020216112P1
24	Rear panel	0020216115P1
25	Front middle pole	/
26	Front right pole	0020216111P1
27	Rear left pole	/
28	Rear middle pole	/
29	Rear right pole	/
30	Back panel	002021619100
31	Left panel	0020216116P1
32	Rear left panel	/
33	Front left panel	/
34	Rear right panel	/
35	Right panel	0020216117P1
36	Front right panel	0020216172P1
37	Front right up panel	/
38	Front right down panel	/
39	Bottom board	002021610100