

Position	Spare parts	Part number
1	PC board (Heat)	033020090000
2	Oval led (Heat)	034090200000
3	4-way valve	006110210001
4	Water flow switch	040060600000
5	Contactator	040010020000
6	Compressor capacitor	041020650006
7	Transformer	036010010000
8	Fan motor capacitor	041010030001
9	Fan motor	032020800000
10	Full set of sensors (Heat)	Z35010010100
11	Compressor	031034060000
12	Titanium heat exchanger (Heat)	001030230000
13	Evaporator	Z01010540000
14	High pressure switch	040050630000
15	Low pressure switch	040050130000
16	High & low pressure valve	006080500000
17	Water union (50mm black)	003990020000
18	Water union gasket	004980050003
19	Drainage kit	Z03991700000
20	Fan	007010030000
21	Top panel	Z03020230109
22	Front panel	Z03020260109
23	Right panel	Z03020230309
24	Back panel	Z03020230609
25	Bottom Board (Black)	002020110100
26	Front left pole (Black)	002020111000
27	Front right pole (Black)	002020111100
28	Back left pole (Black)	002020111200
29	Back right pole (Black)	002020111300